

(i) For anyone to design, manufacture, or install emission control systems so they cause or contribute to an unreasonable risk to public health, welfare, or safety while operating.

(ii) For anyone to design, manufacture, or install emission control systems with features that disable, deactivate, reduce effectiveness, or bypass the emission controls, either actively or passively. However, you may include a vent that the operator can open to bypass emission controls if that vent closes automatically (*i.e.*, without operator involvement). You may include such design features if they operate during emission tests described in subpart F of this part. For example, you may include an integrated or external manually activated device in the portable fuel container's design to temporarily relieve pressure, provided that the device is in place during emission testing and closes automatically when not in use.

(2) *Leaks.* You must design and manufacture your containers to be free of leaks. This requirement applies when your container is upright, partially inverted, or completely inverted.

(3) *Refueling.* You are required to design your portable fuel containers to minimize spillage during refueling to the extent practical. This requires that you use good engineering judgment to avoid designs that will make it difficult to refuel typical vehicle and equipment designs without spillage.

(d) Portable fuel containers must meet the standards and requirements specified in this subpart throughout the useful life of the container. The useful life of the container is five years beginning on the date of sale to the ultimate purchaser.

[72 FR 8533, Feb. 26, 2007, as amended at 80 FR 9089, Feb. 19, 2015]

**§ 59.612 What emission-related warranty requirements apply to me?**

(a) *General requirements.* You must warrant to the ultimate purchaser that the new portable fuel container, including all parts of its evaporative emission-control system, is:

(1) Designed, built, and equipped so it conforms at the time of sale to the ultimate purchaser with the requirements of this subpart.

(2) Is free from defects in materials and workmanship that may keep it from meeting these requirements.

(b) *Warranty notice and period.* Your emission-related warranty must be valid for a minimum of one year from the date of sale to the ultimate purchaser.

(c) *Notice.* You must provide a warranty notice with each container.

**§ 59.613 What operation and maintenance instructions must I give to buyers?**

You must provide the ultimate purchaser of the new portable fuel container written instructions for properly maintaining and using the emission-control system.

**§ 59.615 How must I label and identify the portable fuel containers I produce?**

This section describes how you must label your portable fuel containers.

(a) At the time of manufacture, indelibly mark the month and year of manufacture on each container.

(b) Mold into or affix a legible label identifying each portable fuel container. The label must be:

(1) Attached so it is not easily removable.

(2) Secured to a part of the container that can be easily viewed when the can is in use, not on the bottom of the container.

(3) Written in English.

(c) The label must include:

(1) The heading "EMISSION CONTROL INFORMATION".

(2) Your full corporate name, trademark and warranty contact information.

(3) A standardized identifier such as EPA's standardized designation for the emission families, the model number, or the part number.

(4) This statement: "THIS CONTAINER COMPLIES WITH U.S. EPA EMISSION REGULATIONS FOR PORTABLE FUEL CONTAINERS (40 CFR Part 59).".

(5) This statement: "THE EMISSIONS WARRANTY IS VALID FOR A MINIMUM OF ONE YEAR FROM DATE OF PURCHASE.".

(d) You may add information to the emission control information label to identify other emission standards that